



Hand Surgery Illustrated

This Portion Shows Graphic Material and is intended for physicians only

Brown Scaphoid Technique

Step 1

Through a volar minimal incision over the scaphoid tubercle the *threaded guide pin* is placed with c/arm control.



Step 2

The combination *Depth Gauge/Countersink* instrument is used and the appropriate length screw selected.



Step 3

The *Cannulated Self-Tapping* screw is placed

